

Miele

CHALLENGE.

MASTERED.



Makes ironing a pleasure:
The professional PIB 100 steam ironing system.

Miele Professional. Immer Besser.

PROFESSIONAL IRONING

HAS NEVER BEEN SIMPLER

Laundry care and, in particular, ironing is part of your daily work, but it isn't your core business? To make sure it stays that way and that you can concentrate on your key tasks, Miele can now offer a professional solution in the form of the MIELE PIB 100.

The compact combination of iron, steam generator and ironing table brings together the best of two worlds: As practical as a domestic appliance and yet powerful, fast and durable to perfectly master the challenges of commercial use.



A SYSTEM OF MANY TALENTS

PIB 100 is an indispensable colleague wherever neat attire and immaculate clothing is called for, and where nicely finished laundry should not tie up too much time and staff. Its use pays off particularly in hotels and restaurants as well as in care and nursing homes.

Thanks to its precise and efficient steam technology, this system keeps on ironing blouses, uniforms, favourite trousers and your guests' business shirts to perfection for at least three hours. Delicate evening dresses or jackets are put back in shape by the high-performance steamer.

And why not take the ironer upstairs to do your work? Not a problem: The compact light-weight unit follows obediently at your heels on its low-noise wheels and is set up and ready for work again in next to no time thanks to its patented 1-2-Lift System*.

And it's worth noting that the PIB 100 is so simple to use it can be entrusted to untrained staff or even guests. Thanks to an intuitive display, the ironing system is extremely simple to use and, thanks to its CE certification, insured in the event of a fault.

So don't be surprised if ironing turns out to be the favourite pastime in your company in future.



EVERY CHALLENGE

MASTER CHALLENGES WITH THE PIB 100

When conventional domestic appliances are stretched to the limit in the face of hours of continuous use, the PIB 100 proves to be a strong and enduring allrounder. Its many features are bound to impress in three respects: in terms of convenience, efficiency and durability.



PRACTICAL

CONVENIENCE

1-2-Lift System – Set up and folded away in a matter of seconds

Two movements, no effort – thanks to the patented 1-2-Lift System*, the PIB 100 is ready for use in next to no time and folded together just as fast.

Large water tank – Greater capacity for more laundry

With a capacity of 4.5 l, at least 3 hours of uninterrupted ironing is no problem.

ComfortZone – Large ironing table

The front half of a shirt can be ironed without repositioning the garment.

No worry: If you need to interrupt your ironing to see to other urgent matters, the PIB 100 provides smart assistance. Thanks to its safe **AutoOff** function, the entire system switches itself off automatically after 25 minutes.



TECHNOLOGY FOR PROFESSIONAL RESULTS

Clear and concise display – Assistance at a glance

With the integrated display on the PIB 100, you will always have all the important information you need at your fingertips, for instance the current machine status, descaling intervals and water levels.

Automatic rinsing for unalloyed ironing pleasure

The automatic rinse function removes mineral residue from the steam generator to guarantee full performance at all times.



TROUBLE-FREE OPERATION AND MAINTENANCE

SoftCare hand iron with honeycomb soleplate – Gentle on fabrics

A thin film of steam, unique to Miele, lets the iron glide effortlessly and efficiently over laundry**.

Powerful steam – Professional quality at the touch of a button

With 4 bar steam pressure and 100g/minute delivery, even the thickest of materials is perfectly ironed.



ele



FACTS, NOT HOT AIR

MIELE PROFESSIONAL QUALITY IN DETAIL



Steam ironing system

Display

Water tank [l]

Steam

Ironing surface [W/D mm]

External dimensions [H/W/D mm]

External dimensions (folded) [H/W/D mm]

PIB 100

Single-line, plain text

4.5

4.0 bar, 100 g/minute

1,190/405

970/470/1,510

1,200/470/402

User interface

- Simple commissioning routine with instructions in plain text
- Operating status and service indicators in plain text in display
- Automatic descaling at the touch of a button, depending on the water hardness
- User interface language selectable to cater for different users

Operational safety

- CoolDown - iron switches off automatically after 3 minutes
- AutoOff - steam ironing system switches off automatically after 25 minutes
- Safe operation according to Machinery Directive for commercial applications

Simple handling

- Practical rollers for ease of transportation
- Ready for use in two moves with patented* 1-2 Lift System
- ErgoLift - infinite height adjustment for perfect working height (83-102 cm)
- Two storage compartments for FashionMaster iron and accessories

Highlights

- Large water tank with 4.5 l capacity for long, uninterrupted ironing
- High-quality, particularly permeable ironing table cover
- Iron with patented honeycomb soleplate** for rapid steam distribution and ease of ironing
- Efficient working on large ironing table with ComfortZone for garment shoulders
- Active ironing table – blower and suction function ensures optimum use of steam and positioning of garments
- Large volume of steam and high pressure for a perfect finish on multi-ply textiles
- Integrated heating reduces any build-up of condensate in the table.

Optional accessories

- Clip-on non-stick soleplate to protect sequin and appliqués and avoid glossy patches on dark textiles
- Handy steamer to smooth and freshen up garments on hangers



*Patent EP 2 169 108 B1

**Patent EP 2 233 632 B1

Miele GB
Tel: 0333 230 1347
professional.info@miele.co.uk
www.miele.co.uk/professional

Miele Ireland
Tel: (01) 461 071
professional@miele.ie
www.miele.ie/professional